Fire Blanket

The Extreme Safety Blanket is easy to use and are suitable for putting out small fires and an excellent first extinguisher in a car, boat, caravan or home. The fire blanket can be released and cover the flame in less than five seconds!



Fire blankets can be used to extinguish fires in small electrical appliances (toaster, coffee maker, etc.), rubbish bins, clothes, tabletops fires caused by candles or fat pan fires. In most cases, fire blankets can also be used to wrap around a person whose clothing is on fire.

The Extreme Safety Fire Blanket is manufactured to meet the requirements of Australian Standard AS/NZS 3504:2006.

HOW TO USE:

We recommend that homes have fire blankets that are 1.2 x 1.8m in size. This size is ideal for you to protect yourself while putting out a fire and to smother appliances and this way at least stop the fire from spreading further.

While using a fire blanket, please take following steps:

1. Pull down tabs to release the fire blanket;
2. Place (not throw) the fire blanket over cooking fat fires, keeping hands and face protected behind it;
3. Turn off the heat source;
4. Leave the fire blanket over burnt area for at least 15 minutes or until the heat has dissipated;
5. Call the fire brigade;

To extinguish a clothing fire:

1. Quickly wrap fire blanket around victim;
2. Drop the victim to the ground;
3. Roll the victim on the ground until the fire is out;
4. Seek medical attention;

Please keep in mind that a fire blanket may not work on especially deep grease fire. While the blanket itself probably wont burn, the grease may seep through and start burning again above the blanket. As in any fire situation, always alert others to the fire and make sure you have a safe escape route in case the fire is too big or spreads beyond your control.

Fire blankets are only suitable for one use and will need to be replaced after each application. Always discard a fire blanket that has been used or is broken and get a new one to replace it.

FIRE BLANKET INSPECTION:

Monthly Inspection:

1. Pull tape must be in place;
2. Label is not torn, must be clean & in position;
3. Free from contamination such as oil, grease, insect, etc.;
4. Firmly mounted on wall;

Yearly Inspection:

1. Perform monthly inspetion;
2. Open blanket & check for torn, damages, defraying, crack contamination & pull tapes intact;
3. Dispose if found unfit for use;
4. Replace back with folding instruction;

STORAGE:

Store your fire blanket folded up in its protective box/pouch so that you can easily pull it out if there is a fire. Hang the fire blanket in its pouch on your kitchen wall or another place where you can get it quickly if necessary.

Ensure mounting hook does not get caught on the blanket after installation.

DO NOT INSTALL AT OR NEAR FIRE HAZARD

ORDERING INFORMATION:

FEATURES	Description
PART NO.	01014-FB
SIZE	1.2m X 1.8m
MATERIAL	Fibreglass (fire resistant woven glass fibre fabric)
WEIGHT	400g/m^2
TEMPERATURE	Can withstand temperatures up to 550C
PACKING	PVC Pouch or PVC Rigid box with SAI label

In support of our policy of continuous product improvement we reserve the right to change materials and specifications without notice. Drawings, where used, are not to scale. All dimensions are in millimetres and sizes given are approximate. Where possible, technical MSDS data sheets are made available on the website. All products should be installed and used in accordance with manufacturer's instructions provided. Warning: products may be the subject of registered designs and patents. Refer to website for terms and conditions on warranty.